

PA Power Up & Down

1. Make all mic, mixer, outboard effects, and output cable connections with all devices *off*.
2. Turn on your outboard effects units (if any) first.
3. Turn on your mixer next.
4. Then turn on any speaker or amplifier DSP units.
5. Finally, turn on your amplifiers or powered speakers.

When powering down, reverse the sequence:

1. Turn off power amplifiers and/or powered speakers.
2. Turn off any speaker or amplifier DSP units.
3. Turn off your mixer
4. Turn off all outboard gear.
5. It's then finally safe to disconnect your cables.